

Návod k použití mincovního automatu

SLZA 40, 40V, 40Z, 40VZ, 40G, 40GV, 40GZ, 40GVZ

- Vhodte mince/žetony
- Zámek je odemčen na nastavenou dobu

User guide for coin and token machine for door opening

SLZA 40, 40V, 40Z, 40VZ, 40G, 40GV, 40GZ, 40GVZ

- Insert coins/tokens
- Open the door - the lock of the door is unlocked for a while

User guide for coin and token machine for door opening

SLZA 40, 40V, 40Z, 40VZ, 40G, 40GV, 40GZ, 40GVZ

- Insert coins/tokens
- Open the door - the lock of the door is unlocked for a while

Gebrauchsanweisung für Münz - Zeitsteuerung für Türen

SLZA 40, 40V, 40Z, 40VZ, 40G, 40GV, 40GZ, 40GVZ

- Legen Sie Münzen/Jeton ein
- Öffnen Sie die Tür - das Schloss der Tür ist für eine Weile entriegelt